

KIMTECH PURE^{*} M3 Sterile Pouch Face Mask Donning Procedure

The Science of Comfortable Protection.

Post Hood Donning Procedure

Step 1

Carefully open the protective packaging.



Step 2

While holding the mask through the protective packaging, reach in and separate the head band straps.

Step 3

Pull bands over the head and secure while holding the protective packaging to avoid contaminating the mask.

Step 4

Reach under the hood and pull the gap guard to the inside of the hood.







Step 5

Pinch nose wire into place.



Step 6

Inhale and exhale to check for secure fit.





®/*Trademarks of Kimberly-Clark Worldwide, Inc. or its affiliates. Marques deposees de Kimberly-Clark Worldwide, Inc. ou de ses filiales. ©2010 KCWW. K02031 K4767-10-01